

Connector Views

171. Gauge Assembly

- Green
- Left side of dash
- On dashboard wire harness A

Connector A




- 1 —
- 2 BLU/RED (Ignition key switch input)
- 3 YEL/BLK (Fuel tank unit)
- 4 LT GRN/RED (Engine coolant temp. input)
- 5 RED (TI signal input)
- 6 M/T: GRY (Shift indicator light control)
- 7 BLU/ORN (Fuel consumption select)
- 8 BLU/RED (Driver's seat belt switch)
- 9 —
- 10 —
- 11 —
- 12 —
- 13 GRN/RED (Brake system indicator)
- 14 GRN/YEL (Turn signal indicator)
- 15 —
- 16 —
- 17 YEL/RED (Oil pressure input)
- 18 BLK/YEL (Circuit K52)
- 19 BLU/WHT (VSS input)
- 20 —
- 21 BLU (Circuit F44)
- 22 PNK (Immobilizer indicator)
- 23 WHT/RED (Fuse 18 – Under-dash)
- 24 Canada: BLU/WHT (DRL indicator)
- 25 Canada: YEL (Fuse 6 – Under-dash)
- 26 BRN/WHT (Charging system indicator)
- 27 GRN/ORN (Malfunction indicator control)
- 28 RED/BLU (High beam indicator)
- 29 RED/YEL (High beam indicator)
- 30 GRN/RED (Turn signal indicator)

Connector B



- 1 CVT: LT GRN (CVT controls)
- 2 YEL/RED (EPS indicator)
- 3 RED/WHT (IMA system indicator)
- 4 GRN (Wiper/washer)
- 5 '01-'06: WHT/BLK (Front wiper/washer)
- 6 BLU/WHT (Wiper/washer)
- 7 BLU/RED (Wiper/washer)
- 8 YEL (Fuse 6 – Under-dash)
- 9 WHT/RED (Fuse 18 – Under-dash)
- 10 RED/BLK (Fuse 15 – Under-dash)
- 11 GRN/ORN (Driver's door input)
- 12 LT GRN/RED (Passenger's door input)
- 13 —
- 14 —
- 15 BLU/RED (ABS indicator)
- 16 BRN (G401)
- 17 BLK (G402)
- 18 PNK (SRS indicator)
- 19 BLU/ORN (IMA system)
- 20 WHT/BLU (IMA system)
- 21 —
- 22 RED (Illumination (–))

Connector C (CVT)



- 1 BLU/BLK (ATP P IND)
- 2 WHT (ATP R IND)
- 3 RED/BLK (ATP N IND)
- 4 BLU (ATP L IND)
- 5 LT GRN (Circuit M26)
- 6 WHT/RED (Interlock system)
- 7 WHT/BLU (Interlock system)
- 8 YEL/GRN (Interlock system)
- 9 YEL/GRN (Interlock system)
- 10 GRN/BLK (ATP D IND)